

This quick reference guide to laundry accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

Step 1 Find your model number in this guide. Model numbers that contain an underscore (_) are available in multiple colors. For example, WM4200H_A comes in both White (WM4200HWA) and in Black Steel (WM4200HBA). DLG3401W does not have the underscore as it only comes in White. Be sure to confirm availability and ordering of consistent model colors across washer, dryers, and pedestals if desired.

Step 2 Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- Gas or electric dryer?
- Side-by-side or stacked installation?
- If a side-by-side installation, do you want pedestals?
- If purchasing a gas dryer, is your home natural gas (NG) or liquid propane (LP)?

Step 3 Identify the items you need to purchase for your washer and dryer. Items with a check box need to be purchased separately.

Where to Buy?

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.[†]

Optional Accessories

Purchase by clicking the LG parts & accessories button[†] call 1-800-243-0000.

LG Parts & Accessories



[†]www.lg.com/us/support/lg-direct-service/parts-and-accessories

What Accessories Do I Need to Purchase for My LG Front Load Laundry Pair?

Items in RED with a check box require you to make a purchase

Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER		
	29" Wide Front Load Laundry Pairs	27" Wide Front Load Laundry Pairs
Washers	WM8100HV	WM4500HBA; WM4200H_A(W, B), WM4000H_A(W, B), WM3600H_A(W, V), WM3400CW
Electric Dryers	DLEX8100*	DLEX4500B*, DLEX4200_(W, B)*, DLEX4000_(W, B)*, DLE3600_(W, V), DLE3400W
Gas Dryers	DLGX8101V*	DLGX4501B*, DLGX4201_(W, B)*, DLGX4001_(W, B)*, DLG3601_(W, V), DLG3401W

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.†	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20–120 psi.	
	Dryer Electrical & Venting Requirements A min. 30 Amp circuit is required. (Note: Venting ductwork is not provided and should be purchased separately. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)	
	LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation through your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)	

LG Parts & Accessories

STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

Hoses Included. No Additional Purchase Required.	<input type="checkbox"/> Washer Water Supply Hoses (Hot & Cold)
Steam Dryer Does Not Require a Water Connection	<input type="checkbox"/> Steam Dryer Installation Kit (Only Required for Steam Dryers with * in Listing Above)
<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)
<input type="checkbox"/> Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit	
<input type="checkbox"/> All Dryers Require a Transition Duct Installation Kit	
<input type="checkbox"/> LP Conversion Kit – 383EEL3002D / LPK1 (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	
When installing side-by-side, you can add 2 pedestals or 1 SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+)	<input type="checkbox"/> Pedestal – WDP5V <input type="checkbox"/> SideKick™ Pedestal Washer – WD200CV (Includes all Hoses and Connectors)
When installing in a stacked configuration, you must order a Stacking Kit.	<input type="checkbox"/> Stacking Kit – KSTK2
All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)	<input type="checkbox"/> Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear; Replaces 383EEL9001B)
Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.	<input type="checkbox"/> Drying Rack – MGR62082001 <input type="checkbox"/> Drying Rack – 3750EL1001A (for DLEX4500B, DLGX4501B, DLEX4200_, DLGX4201_, DLEX4000_, DLGX4001_) <input type="checkbox"/> Drying Rack – 3750EL1001D (for DLE3600_, DLG3601_, DLE3400W, DLG3401W)

Optional Accessories

Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000

LG Parts & Accessories

● V – Graphite Steel ● B – Black Steel ○ W – White *Steam dryer †www.lg.com/us/support/lg-direct-service/parts-and-accessories +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord.

What Accessories Do I Need to Purchase for My LG Specialty Front Load Laundry Pair?

Items in RED with a check box require you to make a purchase

Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER				
	WashTower™ with Center Control™	27" All-in-One Washer / Dryer Combos	24" All-in-One Washer / Dryer Combos	24" Wide Compact Front Load Laundry Pairs
Washers	WSEX200HNA, WKEX200H_A(W, B), WKE100H_A(W, V) w/Electric Dryer	WM3998HBA	WM3499HVA WM3488H_(S,W)	WM1455H_A(V, W)
Washers	WSGX200HNA, WKGX201H_A(W, B), WKG101H_A(W, V) w/Gas Dryer			
Electric Dryers	Dryer Included	-	-	DLHC1455_(W, V)
Gas Dryers	Dryer Included	-	-	Not Available

STEP 2: READ THIS INFORMATION

STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.† 	Water Supply Requirements Washers must be connected to a hot water supply with a temperature range between 120°F and 130°F. Required min. / max. water pressure is 20 – 120 psi.		<input type="checkbox"/> Washer Water Supply Hoses (Hot & Cold)	Hoses Included. No Additional Purchase Required.		
			<input type="checkbox"/> Dryer Water Supply Hose (Cold)	Not Applicable		
	Dryer Electrical & Venting Requirements (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)		<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	No Additional Purchase Required	<input type="checkbox"/> Electric Dryers Require a 240V 4-Prong Power Cord (Refer to ** below if you have a 3-Prong outlet)	
			<input type="checkbox"/> Gas Dryers Require a Flexible Stainless Steel Gas Connector Kit	Not Applicable		
		<input type="checkbox"/> All Dryers Require a Transition Duct Installation Kit	Ventless Condensing Dryer Does Not Require Venting	Heat Pump Dryer Does Not Require Venting		
	LP Conversion Kit If ordering a Gas Dryer and your home uses Liquid Propane (LP) instead of Natural Gas (NG), order an LP Conversion Kit. (Kit is not needed if you are ordering an LP Conversion Installation thorough your retailer. In this case, the installer will provide the necessary LP Conversion Kit.)		<input type="checkbox"/> LP Conversion Kit – 383EEL3002D / LPK1 (Not needed if you are ordering an LP Conversion Installation. See details on the left.)	Not Applicable		
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000 	When installing side-by-side, you can add 2 pedestals or 1 SideKick™ and 1 pedestal. (Be sure to order the correct color to match your pair.+)		Not Applicable	<input type="checkbox"/> Pedestal – WDP4B <input type="checkbox"/> SideKick™ – WD100CB (Includes all hoses and connectors)	Not Applicable	
	When installing in a stacked configuration, you must order a Stacking Kit.		WashTower™ Unit Comes in Stacked Configuration. No Kit Needed.	Stacking Kit - KSTK1	Not Stackable	
	All dryers are shipped for Rear Venting. Order a Side / Bottom Adapter Kit to change venting to the Bottom or Side. (Right side venting is not available on gas dryers.)		<input type="checkbox"/> Side / Bottom Vent Kit – 3911EZ9131X (Only Required if You are not Venting from the Rear, replaces 383EEL9001B)	Ventless Condensing Dryer Does Not Require Venting		Heat Pump Dryer Does Not Require Venting
Order a Drying Rack to gently dry shoes, delicate sweaters and more, without tumbling.		Drying Rack Included (WSEX200HNA, WSGX200HNA) <input type="checkbox"/> Drying Rack – 3750EL1001A (for WKEX200H_A, WKGX201H_A, WKE100H_A, WKG101H_A)	Not Applicable			

● V – Graphite Steel ■ S – Silver ● B – Black Steel ○ W – White *Steam dryer †www.lg.com/us/support/lg-direct-service/parts-and-accessories +An underscore in the model number “_” indicates the model is available in multiple colors. Confirm color availability for the pair you are purchasing and be sure to order the same color for the washer, dryer, and pedestals. **A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong dryer power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong dryer power cord. LG recommends a 4-wire connection and a 4-prong dryer power cord.